

# BookDrive DIY AutoSwitch Installation Guide

 <p>1. You need to remove this screw.</p> <p>Note: AutoSwitch is designed to install on left side of the BookDrive.</p>	 <p>2. Loose the second screw about ¼ inch.</p>
 <p>3. Insert Autoswitch by put the groove on the 2<sup>nd</sup> screw and then slide it parallel with the column.</p>	 <p>4. Slide the coupling into the plate's holder.</p> <p>Note: You need to lift the plate's holder a bit to insert the coupling.</p>
 <p>5. Loose the upper screw to insert Autoswitch completely.</p> <p>Note: After install the Autoswitch please tight the screw to complete the installation.</p>	 <p>6. Please put this side up when install the cable.</p>
 <p>7. Carefully insert USB cable into the Autoswitch. And then connect it to PC.</p>	 <p>7. You have successfully installed the Autoswitch with the BookDrive DIY.</p>