1

Set up hardware.


www.atiz.com/support/mini

Safety Precautions


Assemble everything on the floor first. Once the assembly is complete, carry the whole machine with at least 2 persons from the floor to the table.

- Place the machine on a level surface to ensure proper working condition. Do not tilt the machine.
- Do not place the machine near heaters or volatile, flammable or combustible materials that may catch fire.
- BookDrive Mini is not designed to be lifted. Do not lift or relocate the machine once it has been fully assembled. To relocate the machine, de-assemble it into parts first and then re-assemble them again at the desired location.

Box Contents



Dimension and Weight




Dimension:

Depth: 40 inches Width: 32 inches Height: 34 inches


Weight: 26 kg. (57 lbs.)

Page Size Support

BookDrive Mini supports pages that are within 10 x15 inches. Some supported standard sizes include:



Part Identification



How to Assemble



1. Pull the cardboard holder straight up.



Place the cardboard holder on 2. the floor.



3. Use 2 people to lift BookDrive Mini out of the box. Hold the metal structure when lifting.



4. Lift BookDrive Mini out of the box as shown.




5. Place BookDrive Mini on a table that is level and strong enough to withstand at least 30 kg. (70 lbs.)




Slowly disassemble the card board holder.


How to Assemble



7. The cardboard contains the camera mounts, LED, bolts, light bulbs, magnetic book holders and hexagon screwdriver.




Install the camera mount by inserting it into the slot.




The camera mount once installed should look like this.



10. Install the light bulb into the lamp.




11. Hold lamp with both hands, place it on top on the platform




12. Hold lamp with both hands, place it on top on the platform


How to Assemble



13. There are two holes for connecting with the switch. Then completely to connect the two switches



15. You have successfully assembled BookDrive Mini



14. The switch is in the right hand side of the user. Please turn on every time that you use the BookDrive Mini.

Counter clock wise the steel bar on LED set to support the cover.



16. You have successfully assembled BookDrive Mini