

## Getting to know your BookDrive N




## How to assemble


1. Take the machine out of the box. The bulk of the machine is already assembled. You just need to connect its arms and cover it with the included shade.




- 2. Connect the LED light bar on the top front part of the machine.
  - 2.1 Move front light hangers in the front to their positions and lock them with knobs both left and right.




2.2 connect the LED light bar on the light hangers and lock it with knobs.




- 3. Connect the main camera mounting arm to its slot located at the top back part of the machine.
  - 3.1 Move rear light hanger to their positions and lock them with knobs.




3.2 Connect the main camera mounting arm to its slot located at the top back part of the machine.




## 4. Tighten all 10 bolts.




Once properly connected, it will look like this.




5. Attach the body shade to the machine as shown below.




6. Cover the top with the top shade.



7. Plug in the cables as shown here. The machine is now ready to use.





- 8. Generally recommended camera settings (can be adjusted to suit your need and preference):
- F stop: F5
- Shutter speed: 1/60 sec
- ISO: 200

